

# A Suite of Methods Utilizing Tensioned Metastable Fluid Detectors for Active Cargo Interrogation to Interdict Special Nuclear Materials

Alex Hagen<sup>(1)</sup>, Brian C. Archambault<sup>(2)</sup>, Anthony Sansone<sup>(1)</sup>, Tom Grimes<sup>(1)</sup>, Rusi P. Taleyarkhan<sup>(1)</sup>

*(1) Purdue University, (2) S/A Labs, LLC., \* Corresponding Author*



February 26, 2016 at MFARL Internal Presentation  
Lafayette, IN

# TMFD Methods for Active Interrogation of Cargo: An Overview

## General System Improvements

- ⇒ ~~Design and construct “paddle” (50%)~~
- ⇒ ~~Design and construct LW-MCTMFD (80%)~~
- ⇒ ~~Acoustically instrument CTMFDs (60%)~~
- ⇒ ~~Multiplicity in CTMFD/ATMFD (25%)~~
- ⇒ Develop DFP EATMFD and PZT Filter

## Photofission Cargo Interrogation

- ⇒ ~~Proof of concept for indirect  $\gamma$  exposure~~
- ⇒ Proof of concept for direct  $\gamma$  exposure
- ⇒ Proof of concept with source/detector shielding/collimation
- ⇒ Design rad-hardness into MCTMFD system

## Threshold Energy Neutron Analysis (TENA)

- ⇒ ~~Proof of concept using CTMFDs for TENA~~
- ⇒ ~~Proof of concept using ATMFDs for TENA~~
- ⇒ ~~Optimization using density, meniscus, and sensitivity compensation (90%)~~
- ⇒ ~~Characterization of S, M, L, C, CH (70%)~~

## Differential Die Away Analysis (DDAA)

- ⇒ ~~Proof of concept with pulsed DT and DATMFD (25%)~~
- ⇒ Proof of concept with pulsed DT and EATMFD
- ⇒ Temporal simulation for pileup, transient pressure field, and multiplicity

# Acoustic Instrumentation of CTMFDs: Motivation and Concept

## Motivation

- ⇒ Cavitation detection time uncertainty is driven by vapor column creation time
- ⇒ Cavitation detection time uncertainty currently is too high for quick resolution of multiplicity
- ⇒ Piezoelectric means may be preferable when in intense  $\gamma$  environments

## Methodology

- ⇒ Piezoelectric device(s) attached to CTMFD bulb provide evidence of shock traces
- ⇒ Filter removes electronic noise and drive frequency
- ⇒ High speed ADC system detects rise in PZT signal




Figure 1: Shock trace using 3 kSps data rate

# Acoustic Instrumentation of CTMFDs: System Concepts




Figure 2: Flowchart of integrated system concept




Figure 3: Flowchart of fast system concept

## Beaglebone MCU - Integrated system

- $\Rightarrow f_{data} = 200 \text{ kSps}, T_{data} = 5 \mu\text{s}$
- $\Rightarrow t_{data \text{ frame}}$  is continuous
- $\Rightarrow$  Requirements: 1 MCU, 1 battery, 1 power board, 1 filter

## Tiva C Delphino MCU - Fast system

- $\Rightarrow f_{data} \Rightarrow 1 \text{ MSps}, T_{data} = 1 \mu\text{s}$
- $\Rightarrow t_{data \text{ frame}} = 45 \text{ ms (45 kS)}$
- $\Rightarrow$  Requirements: 1 MCU, 1 wireless connection board, 1 battery, 1 power board, 1 filter

# Acoustic Instrumentation of CTMFDs: Achievements

## What have we actually done?

- ⇒ Beaglebone MCU taking data at 200 kSps and continuously sending to computer over WiFi
- ⇒ Delphino MCU taking data at 1 MSps and sending to computer over USB (Tony)
- ⇒ Filter created with acceptable envelope
- ⇒ Power input filter created for BB MCU
- ⇒ Detection event comparisons using Bertholet tube (Tony)

## What do we still need to do?

- ⇒ Integrate BB MCU with power input filter, pzt input filter, and battery
- ⇒ Design and 3d print “harness” for Integrated system on board
- ⇒ Test BB MCU on LCTMFD
- ⇒ Program Delphino MCU to send data to a WiFi Board
- ...

# Paddle C/CH-CTMFD System: Motivation and Concept

## Motivation

- ⇒ Achievement of  $2.5 \text{ cps/ng}$
- ⇒ Competition against “Paddle” from Symmetrica (R)

## Methodology

- ⇒ Five 65 cc/100 cc “C”/“CH”-CTMFDs
- ⇒ Stacked with cap closure - hose across for continuous pressure
- ⇒ DC motor able to spin to 60 rps (10 bar)
- ⇒ Triple bearing assembly for alignment
- ⇒ Precision Balancing Inc. for balancing
- ⇒ XBee or BB MCU for data transmission

## Paddle C/CH-CTMFD System: Accomplishments

- ⇒ Machining out to machine shop
- ⇒ Glassblowing out to Superior Scientific Glass
- ⇒ Power supply identified (48 V, 10 A) - to be purchased
- ⇒ Instrumentation possible through BB MCU or XBee
- ⇒ Estimated delivery 3 - 5 weeks




Figure 4: Design of Column C-CTMFD Revision 0

# Lightweighting of M-CTMFD: Status of the Project




Figure 5: Design of Lightweight M-CTMFD Revision 2

- ⇒ Continuous current needed measured ( $< 3$  A for 4 bar)
- ⇒ Power supply purchased - able to run 2 systems (Brian)
- ⇒ Plate, Bearing and shaft out to machine shop
- ⇒ Shortened base received this week
- ⇒ Estimated delivery 1 - 2 weeks



# Threshold Energy Neutron Analysis: Concept




Figure 6: Threshold Energy Fission Discrimination

# Threshold Energy Neutron Analysis: Accomplishments

Table 1: Accomplishments with different TMFD Detectors at using TENA to discriminate fission neutrons

| Name       | Sensitive Volume | No Temperature Compensation<br>$r_\eta$ | Density/Meniscus Compensated<br>$r_\eta$ | Full Compensation<br>$r_\eta$ |
|------------|------------------|---|--|-------------------------------|
| M(s)-CTMFD | 3 cc             | 17                                      |  |                               |
| M-CTMFD    | 15 cc            | 132                                     | $< 1.7 \times 10^4$                      | Planned for 3/16              |
| L-CTMFD    | 40 cc            | $> 1 \times 10^4$                       | $< 2.5 \times 10^4$                      | Planned for 4/16              |
| C-CTMFD    | 65 cc            | 538                                     | Planned for 3/16                         | Planned for 4/16              |
| CH-CTMFD   | 100 cc           | -                                       | Planned for 3/16                         | Planned for 4/16              |
| EATMFD     | 170 cc           | $< 1$                                   |  |                               |
| Acetone    |                  |   |  |                               |
| TEATMFD    | $\sim 200$ cc    | Planned for 9/16                        |  |                               |
| DFP        |                  |   |  |                               |
| DATMFD     | 35 cc            | Planned for 9/16                        |  |                               |
| Acetone    |                  |   |  |                               |

# Threshold Energy Neutron Analysis: Temperature Compensation (1/2)

- ⇒ Currently adjust density using correlation shown at right
- ⇒ Adjust meniscus using experimental values for meniscus at different temperatures (linear)
- ⇒ Apparent “plateau” of threshold pressure at  $> 25^{\circ}\text{C}$




Figure 7: Currently used density correlation to adjust density and meniscus




Figure 8: Analysis of waiting times at varying temperatures

# Threshold Energy Neutron Analysis: Temperature Compensation (2/2)




Figure 9: Evaporation rate of DFP with different constant temperatures




Figure 10: Calculated  $\Delta h_{vap}$  from Clausius-Clapyron equation and experimental or Antoine values for boiling temperature and vapor pressure

⇒  $\Delta h_{vap}$  correlations from several sources shown to left

⇒ No large change in values around 25°C

⇒ Other parameter must be the reason for threshold "plateau"

## Threshold Energy Neutron Analysis: Proposed Plan (2/16 - 5/16)

- ⇒ Determine threshold pressure at 22°C
- ⇒ Adjust data for average instead of centerline negative pressure
- ⇒ Develop  $p_{neg, stp\ equivalent}$  relation
- ⇒ Validate TENA with this in M-CTMFD
- ⇒ Continue to characterize C-, CH- CTMFDs

## Interdiction of SNM with photofission:

- ⇒ TMFDs are  $\gamma$  blind
- ⇒ Much  $\gamma$  interrogation infrastructure is already in place
- ⇒ Suffers background from  $^2\text{H}$  and  $^{13}\text{C}$




Figure 11: Uranium ( $\gamma, n$ ) and ( $\gamma, f$ ) cross sections at  $< 7$  MeV




Figure 12: Results from preliminary test with CLINAC

## Interdiction of SNM with photofission: Proposed Plan (5/16 - 7/16)

- ⇒ Return to CLINAC for experiment (5/16 - 6/16) with
  - PFO
  - PFPE
  - Floor shielding
  - Detector shielding
  - Use of broken fission detector for HEU source
- ⇒ Perform MCNP6 assessments of photoneutron production rates in ANSI standard cargo

# Differential Die Away Analysis: Introduction




Figure 13: Differential die away analysis schematic



## Differential Die Away Analysis: Proposed Plan (10/16 - ...)

- ⇒ Develop TEATMFD for use with DFP
- ⇒ Develop filter for “directionality” in TEATMFD with DFP
- ⇒ Perform temporal pressure analysis in TEATMFD with COMSOL
- ⇒ Pulse DT generator while TEATMFD is sensitive
- ⇒ Run DD generator continuously while TEATMFD is sensitive and time-veto cavitations after detection